

780582, Kit Magnet Waste Bin FK-2 Series, FK-3 Series, & CX-2 Series

Kit Consist of: **121301**: Magnet [1/2"x1-1/2"x1/4"] 1 ea. **700040**: Screw #6x5/8" SPHSMS SS 1 ea. **780580**: Retainer – Magnet SS POD Drawer 1 ea. **780581**: Instruction Sheet 1 ea.

Installation:

- Turn your waste bin upside down with back edge facing you.
- Take the retaining bracket and slide it on to the waste bin's outer wall. The long flange on the bracket should be on the outside of the outer wall. The "J" bend on the bracket should be over the edge to the inside of the wall.
- Next take the magnet and insert it fully into the retaining bracket's "J" bend or cradle on the interior portion of the waste bin back wall.
- Line up [center] the magnet /retaining bracket in line with the circle located in the center of the waste bin.
- Once centered use the #6 screw, provided, using an electric screwdriver to anchor the retaining bracket/magnet to the waste bin.
- Job is complete.

